

6-row Idealliance Large Format-Industrial-Textile Printing Control Wedge 2019 and i1Pro/i1iO Instructions


NOTE: This control strip will only work with the i1Pro 3 PLUS and i1iO 3 PLUS

Setting up i1Profiler for the first time

- Step 1. Plug the i1Pro 3 PLUS or i1iO 3 PLUS into the computer
- Step 2. Launch i1Profiler
- Step 3. Select:
User Mode: *Advanced*
Device Selection: *CMYK Printer*
Workflow Selection: *Measure Reference Chart* (An Assets panel will be displayed on the left side)
- Step 4. Right-click anywhere in the Assets panel (Mac/Windows) or Control + Click (Mac) to display a contextual menu
- Step 5. Select *Show in Finder* (Mac) or *Open Containing Folder* (Windows) from this menu to access the folder
- Step 6. Copy the *Idealliance LFP Digital Control Strip 2019 (i1Pro-i1iO).rwx* file into the MeasureReferenceWorkflows folder
- Step 7. Close the MeasureReferenceWorkflows folder
- Step 8. Refresh the Assets panel by clicking the circular arrow button in the right corner of the Assets panel title bar

Using i1Profiler after initial setup

- Step 1. With Device Selection set to *CMYK Printer*, click *Measure Reference Chart*
- Step 2. Double-click the *Idealliance LFP Digital Control Strip 2019 (i1Pro-i1iO).rwx* file in the *Saved Workflows* list in the Assets panel
- Step 3. Select the connected device from the pop-up list at the top of the screen (*i1Pro 3 PLUS*, *i1Pro 3 PLUS M3*, *i1iO 3 PLUS*, or *i1iO 3 PLUS M3*)
- Step 4. Click the Next arrow icon or click the Measurement icon at the bottom of the screen
- Step 5. Select the *Single scan* Measurement Mode radio button
- Step 6. For i1Pro 3 PLUS click the *Calibrate* button below the picture of the control strip and then measure the six rows, or for i1iO 3 PLUS click the *Measure* button and follow the onscreen instructions to align the i1iO to the control strip corners
- Step 7. When finished measuring all six rows click the *Save* button above the Measurement icon at the bottom
- Step 8. Set *Files of Type* to *i1Profiler CGATS Custom (*.txt)*
- Step 9. Choose a name and location to save the file and click the *Save* button
- Step 10. Set the Custom CGATS Options window to these values:



- Step 11. Click the *OK* button
- Step 12. There will be 3 files created with an *_M0*, *_M1*, and *_M2* appended to each file name